


AUTOMATIC SCREW FEEDER FOR ROBOT 轉盤式精密螺絲供給機

Operating Instruction 使用說明



Thanks for purchasing this product.
The product is electrical automation equipment.
Please strictly abide by the use of norms.
Please read the manual before using the machine, and
keep it safely. In case of any insurmountable problems,
please contact the dealer.



警告

WARNING

謝謝您選購本產品！

本產品屬於電氣自動化設備，請嚴格遵守使用規範。
使用之前請仔細閱讀此說明書，閱讀之後請妥善保管。
如遇任何不能解決的問題，請聯系經銷商。

版本号：20200609

CONTENTS

目錄

Characteristics 螺絲機特點	1
Before use 使用之前	2
Parameters 螺絲機參數	6
Discription of parts and functions 部件及功能描述	6
Fault solution 常見故障處理方法	7
Operating Instruction 使用說明	8
Operation 使用方法	8
Adjustment methods 調節方法	8
Parts Description Figure 部件說明圖	10
Precautions 注意事項	15
Components in Chinese and English name of the table 部件中英文名稱表	16

Characteristics

1. Adjustable for a wide range.

The rail can be adjusted freely to suit many kinds of screws, like M1.0-M5.0 standard screw (1.0 1.2 1.4 1.7 2.0 2.3 2.6 3.0 3.5 4.0 5.0), special screw, 1:1 short screw, filling piece screw and so on.

2. Working smoothly.

The screws movement and fall down inside the bucket all the screws will be cleared if not enter the rail and enter the next circle, screws will never be blocked, the check point will not vibrate.

3. Working speed adjustable

Feeding system and drive system independent control, set the time delay freely to adjust the feed speed, suits many kinds of works.

4. Simple operation

Whether metric specifications or british specifications, all easily to understand, even novices can operate freely.

5. Can increase productivity significantly

It is unnecessary to target the screw cap, compared to screw plate, each screw can save 1.4 seconds, productivity increased by 4 times!

6. Statistical function (partial models)

When the settings achieved, the machine will automatic alarm and cycle, it is very clear to see with digital display panel.

7. Automatic alarm function

When non-normal condition occurs, the machine can automatic alarm.

8. The volume is exquisite, does not occupy the space.

螺丝机特点

1. 可調型，適用範圍廣

軌道可自由調節，廣泛適用多種類型和長度的螺釘，如M1.0-M5.0標準螺絲（1.0 1.2 1.4 1.7 2.0 2.3 2.6 3.0 3.5 4.0 5.0），特殊螺絲，1:1短螺絲，帶墊片螺絲等。

2. 運轉流暢

螺絲在滾筒內運動，凡是未進入軌道的螺絲，都會被清除到滾筒內，進入下個循環，無卡螺絲現象，取點位置不會前後抖動。

3. 工作速率可調

送料與振動驅動獨立控制，可自由設定理想的延時停止時間，以調節螺絲進料速度快慢，適合多種作業。

4. 操作簡單

操作方法不管是公制規格還是英制規格，皆能操作自如，簡單易懂，即使生手也能馬上學會。

5. 可大幅提高生產率

不必對正螺釘頭位置，比起傳統螺絲盤，每顆螺釘可節省1.4秒，生產效率提高4倍！

6. 有計數功能（部分型號）

計數功能自動報警、循環，帶數字顯示面板，一目了然。

7. 有故障報警功能

當非正常情況產生時，螺絲機會自動啟動故障報警裝置。

8. 體積小巧，不占空間

Read these instructions thoroughly for the proper use of this machine. After having read these instructions, keep them in a safe place so that you or the operator can refer to them whenever necessary.

一、Fittings

Instruction manual, 1 copy
Screw stopper plate, 1 piece
1.2mm trim areas 3 piece of,
0.2 mm trim area 5 pieces (used for adjusting the holding plate)
Hexagonal key, 1 piece

二、FOR SAFE USE

Read the following Cautions thoroughly for the safe use of this machine. Keep them in mind during the operation of the machine in order to prevent injuries and damage to property.

Installation Caution:

Install the machine on a level, stable location that can endure its weight and running conditions. If the machine falls down or turns over due to improper installation, injuries or property damage may result.

為了正確使用該設備，請仔細閱讀說明書，讀完這些操作說明後將它保存在一個安全的地方，以便你或者操作者需要時，隨時可以查閱并遵照說明操作。

一、附件



說明書1份



直流電源



1.2調整片3片、0.2調整片5片(用于調整軌道間隙)

內六角扳手一個

二、安全使用

為安全使用此機器請仔細閱讀完下列注意事項

機器安裝

安裝此機器要在一個水準、穩定且能够承受機器重量和進行條件的位置上安裝，如果非正常安裝操作，將會導致機器非正常關閉或者落下，甚至人身受傷或財產損失。

操作環境

不要在有易燃或腐蝕性氣體環境下操作此機器，在這種環境下使用此機器是非常危險的，不要在溫度很大的環境下操作此機器

Operating Environment

Caution: Do not operate this machine where flammable or corrosive gas is present. It is extremely dangerous to use this machine under such circumstances. Do not operate this machine in environments of high humidity.

AC adapter

Caution: Do not use any other AC adapter other than the recommended accessory.

Rail

Caution: Do not damage nor oil the rail. Suitability of screws

Caution: Do not use oily screws, dirty screws or any screw other than those prescribed.

Screw removal

Caution: Do not exert excessive or impactive force when removing the screws.

When the machine doesn't work

Caution: Be sure to unplug the AC adapter from the wall outlet during closing hours and if the machine will be left unused for any extended period of time.

Emergency

Caution: Stop operation and unplug immediately whenever you sense abnormalities or anomalies during the operation of this machine, such as a pungent odor. Turn off the power switch and disconnect the AC adapter from the receptacle. Continued operation may cause fire, electric shock, malfunction or injury. Immediately contact the dealer from which you purchased the machine.

Servicing

Caution: Do not attempt to repair, disassemble or modify this machine except where specified by this manual. Consult your dealer for service and repair of this machine.

电源适配器

請使用本機附帶的電源，不要使用別的電源适配器。

軌道

注意：不要損壞和潤滑軌道。

適用的螺絲

注意：不要使用有油漬的螺絲，臟螺絲或其他任何一款規定外的螺絲。

取螺絲時

注意：用電批取螺絲時不要過度用力或給予較大的衝擊力。

當機器不工作時

注意：如果休息或者長時間不工作時，請將電源拔出。

緊急處理

注意：當你在操作機器過程中發現有異常現象，譬如刺耳的聲音時，請立即停止機器運行，關掉電源開關，切斷适配器連接。如果繼續進行可能會導致失火、短路、性能失效或其他損壞。所以出現上述情況請及時與供應商聯系。

售後服務

注意：不要試圖自行拆分、修理機器尤其是說明書中特別提到的部分。有問題時請聯系你的供應商，請求售後服務并進行維修。

三、ADJUSTMENT AND CHECKS BEFORE USE

Before use, check if components suited to the screws are fixed to the body. The rail is $\phi 1.0$ to $\phi 5.0$ depending on the nominal diameter. It is determined by a discriminating seal affixed on a rail front cover. There are two kinds of passage plates, namely one for $\phi 1.0$ to $\phi 1.7$ and one for $\phi 2.0$ to $\phi 3.0$. It is determined by a discriminating seal affixed on a passage window. The size of the different screws adjustable guide replace the turntable and the upper plate. The upper plate and the turntable can be bought from our company.

1. Attaching a rail to a main body

First, loosen the fixing screw and thrust the rail until it stuck at end as shown in the picture. Then, tighten the fixing screw before.

2. Quantity of screws thrown in

If too many screw are thrown in, orientation and transfer of the screw will be seriously affected.

3. Check/adjustment of the brush

Check the height of the brush. As in the picture on the right, set the brush to an approximately level position. Ensure that the edge of the brush is grazing the screw's head. If the height of the brush is either too low or too high, orientation and transfer of these screws will be seriously affected. If adjustment is necessary, adjust it by loosening the brush height adjusting screw.

Note: Always unplug the AC adapter from the wall outlet before making any adjustments to avoid injury.

4. Check/adjustment of the plate

Check the position of the plate. Ensure that the gap between the head of the used screw in the rail groove and the plate is approximately 0.2mm to 1 mm. If there is no gap, the screw gets caught. If the gap is too large, the screw overlaps or juts out. If adjustment is necessary, adjust it up or down by loosening the bit guide bracket attaching screw.

5. Easily adjust it by using the 0.35 mm gauge plate. Loosen the bit guide bracket

三、使用之前的機器調整和檢查

使用之前先檢查軌道寬度和壓板高度是否適合螺絲，軌道 $\phi 1.0$ – $\phi 5.0$ 取決於放入的螺絲的直徑，不同的螺絲可調導軌的大小，更換轉盤和上板。（上板和轉盤可通過供應商購買）。

1. 檢查軌道安裝

首先，鬆開固定好的螺絲，將導軌推到如圖所示的地方卡住，然後將螺絲像以前一樣固定好。



2. 放入螺絲的數量

不要一次性放入太多的螺絲，否則會影響到螺絲的移動方向和傳送速度。

3. 刷子的檢查/調整

檢查刷子的高度

如右圖所示，將刷子安裝在一個近似水準的位置，確保刷子的邊緣可以刷到螺絲的頭部。

如果刷子的高度太高或太低，都將會嚴重地影響到螺絲的移動。

如果需要調整，那就先鬆開毛刷的螺絲來適當調整刷子的高度。

要點：為了避免損壞機器，調整機器前請把電源拔出。



attaching screw. Insert the gauge from the top between screws on the rail and the holding plate. Tighten the bit guide bracket attaching screw when the holding plate is touching the front and the back of the gauge equally.

Caution: Match the center of the holding plate out let and the rail center may be necessary. If not, adjust it by loosening the attaching screw.

6. Check/adjustment of the rail. Check the physical relationship of the stopper and sensor. Ensure that the rail is fixed so that "A" portion of the stopper is 0 mm to 0.5 mm ahead of the sensor optical axis. If adjustment is necessary, adjust it back and forth by loosening the rail attaching screw.

7. Check/adjustment of the turntable

First: To choose the correct aperture and top plate for the screw, and adjust the aperture and the top plate to center align

Second: Adjust the rail for the screw slipping smoothly.

Third: To check the aperture and rail center align when the machine is working, and then tighten the screw if they were center align. There is 0.3MM gap between the aperture and the rail. And then adjust the gap between the rail and plate until the screw can be slipped smoothly.

Fourth: The secondary alarm caught with the hand wheel, wheel idling will call the police ten times in the boot when using this product if the circumstance that does not have to report to the police, please restart to get a clear indicator

8. Check/adjustment of rail vibration

Transfer speed of screws differ according to screw type. This machine can change rail amplitude and adjust the transfer speed. To adjust amplitude, loosen an amplitude fixing screw at the rear of this machine and turn the amplitude adjusting screw at the bottom of the machine. Viewing it from the bottom, if turned clockwise, the amplitude become larger, and if turned counter clockwise, the amplitude becomes smaller.

If you make the amplitude too large in order to speed up the transfer, it may become difficult to pull up screws. So, adjust it to appropriate amplitude for the type of screw being used. After adjustment, be sure to tighten the amplitude fixing screw on the rear of the machine.

4. 壓板的檢查

確保從壓板出來的螺絲頭部和壓板之間的間隙在0.2–1mm之間。如果沒有間隙，螺絲不能正常出來；如果間隙過大，螺絲會重疊；如果需要調整，鬆開壓板上的螺絲上下調整。

5. 用調整片輕鬆調整壓板間隙

鬆開導向槽的螺絲，塞進調整片輕輕下壓壓板鎖緊螺絲即可，確保壓板在導軌的中間。

6. 軌道的檢查和調整

檢查擋料鉤和感測器的位置，擋料鉤A點和感測器的中心在同一條線上或者超出中心0.5mm。

7. 轉盤的檢查和調整

檢查轉盤和導軌在工作中，轉盤開口處和導軌是否對應。應後鎖緊固定螺絲。轉盤和導軌連接處間隙約為0.3mm，軌寬度和壓板高度是否適合螺絲，檢查螺絲，選擇相應的上板和轉盤，轉盤和上板的圓需保證同心，導軌可調，用手卡住轉盤十次要報警，轉盤空轉十次要報警，在剛使用本產品時，開機如果料沒有到的情況下報警，請重新開機，料到鳴指示燈亮，（轉盤和上板規格詳見附圖）。

8. 軌道振動的檢查和調整

螺絲的傳送速度因螺絲型號不同而不同。此螺絲機根據改變馬達速度來調整螺絲的傳送速度。如果馬達速度使軌道振幅很大，那麼要使螺絲機停下來變會變得比較困難。所以應按照正在使用的螺絲的型號來調整軌道的速度以達到最合適的狀態。

9. 檢查感測器的中心

如果取料口沒有螺絲，感測器繼續運作，螺絲機就會一直工作，如果有螺絲，感測器每過一段時間停下來。螺絲機對有無螺絲的感應可按照上述提到的方法來調整。如果有必要使用很小的螺絲時，就調整感測器的位置。

9. The machine continues operation if there is no screw at the feeding mouth, and there are screws machine stops after a certain period of time has passed. The machine has the level of the screw/no screw sensor adjusted by the reference rail on shipment. However a level adjustment of the sensor is necessary when using thin-head screws.

Parameters

Screw head: Suits each type of screw (Lmax=1.0mm)
 Output speed: 1 screw / s $\pm 0.3/s$
 Input voltage: AC220V-240V 50Hz
 Product size: 202.5mm x 126mm x 149mm (L*W*H)
 Net weight: About 3.0 kg
 Accessories: Operational Guidelines,
 DC power supply (input 220V-240V, output DC15V/1200mA)
 inward hexagonal key

螺丝机参数


螺釘頭：適合各種型號螺絲 (最長L=10mm)
 輸出速度：1粒/秒 $\pm 0.3s$
 輸入電壓：AC220V-240V 50Hz
 產品尺寸：202.5mm x 126mm x 149mm (長x寬x高)
 淨重：約3.0kg
 附帶配件：操作指南，直流電源 (輸入220V-240V，輸出DC15V/1200mA)
 內六角扳手

常見故障處理方法

Fault solution

Description of parts and functions

部件及功能描述



Fault	Reasons	Solution
No power	1. Power supply is damaged 2. Switch damage 3. DC socket is problem	Check for update
Indicator lit but the machine does not work	1. Sensor located in wrong location or was blocked 2. The power cord motor is broken 3. Working parts of the machine are blocked (gear eccentric)	1. Check or adjust 2. Re-welding 3. Remove them from the machine
Screw was blocked in rail Screw leak out from material container	Rail gap, platen or brush Position is wrong The apron of material container located in wrong location	Check and adjust Adjust the apron position
Signal light has been lit	1. To shoot the bad 2. Sensor bracket sinking	1. Check for update 2. Check and adjust
Keep vibrating and no stop	1. Feeding delay is too long 2. Sensor located in wrong location 3. Screw is not in the right position	Check and adjust Sensor is not in the right position
Screw transportation is too slow	1. Feeding speed is slow 2. delay time is too short 3. The gap of the rail is not suitable 4. The rail touches the board 5. No gap between rail and front board 6. There are dropped Screws between vibratory motor and bottom board	1. Adjust the motor speed 2. Increase the feeding delay 3. Adjust 4. Adjust the gap 0.5~1mm 5. Adjust the gap 0.5~1mm 6. Remove the dropped screws

故障	原因	處理方法
螺絲機沒電	1. 電源壞 2. 開關壞 3. DC插座壞	檢查更新
電源燈亮機器不工作	1. 出口感測器沒對好位置或物品擋住 2. 馬達電源線斷 3. 螺絲機活動部件被卡住 (偏心輪處, 齒輪處)	1. 檢查或調整 2. 重新焊接 3. 清除活動部件異物
料道卡螺絲 料倉漏螺絲	刷子高低、料道間隙、壓板位置未調好 料倉擋板上下左右位置未調整好	檢查後做相應調整 調整擋板位置
信號燈長亮	1. 對射傳感器壞 2. 傳感器支架下沉	1. 檢查更新 2. 檢查後做相應調整
出口一直振動不停	1. 直振送料延時太長 2. 出口感測器位置不合適 3. 螺絲尾部沒在感測器感測範圍內	做相應調整
出螺絲太慢	1. 送料供料速度慢 2. 延時時間短 3. 導軌間隙調整不合適 4. 擋板頂住導軌 5. 導軌與前板處無間隙 6. 振動電機與底板之間有異物	1. 調長送料供料延時 2. 調整馬達速度 (SPEED) 3. 做相應調整 4. 調整間隙 (0.5~1毫米) 5. 調整間隙 (0.5~1毫米) 6. 清除異物

Operations

1. Adjusts parameter suitable (the methods will be told next).
2. Open the lid, pours into groups the bolt for the material stock .
3. Turn on the powre button, put the electric screwdriver head into guide slot. down along the guide slot. pull out the screw bolt go straight

使用方法

1. 調整好適合的參數（調整方法見下面）。
2. 打開倉蓋，將螺絲釘成批倒入供料室。
3. 打開電源，把批頭放入批頭導向槽處，順着導向下滑，然後朝面前拉出螺釘即可。

调节方法

Adjustment methods

调节方法

1. 料道調節



Release the screw on cover with hexagon wrench, pullout rail .

用內六角扳手鬆開料道擋板上一顆螺絲，拉出導軌

Adjustment methods



One end by adjusting the location of the two screws to adjust the track width. the other side by increas or reduce the number of small pices to adjust the gap.in order to adapt to different sizes of screws. After adjustment locking screw.

一端通過調整兩個螺絲的位置來調整軌道寬窄，另一端通過加減小片來調整間隙，以此來適應不同大小的螺釘，調好後把螺絲鎖緊。



Adjust the brush position according to the screw size. Under normal circumstances, after the formerhigh-low

根據螺釘大小調整刷子高低位置，一般情況下調整為前低後高

2. Speed adjustment

(1)Characteristics of motor speed:



Speed adjust-ent buttons
速度調節鍵


2. 速度調整

(1)振動馬達速度（SPEED）特性：
Guide（V導軌）



Adjustment tools
調節工具

The graph for motors speed and rail speed.



馬達速度和導軌速度關係

(2)Roller delay adjustment:
when the screw is large or not conducive to access to rail, increase the roller delay, in contrast reduce it.

(3)Guide vibration delay adjustment:
The same, when the screw is targe or not conducive to access to rail, increase the roller delay in contrast reduce it.

(2)上料轉輪延時（ROLLER）調整：
當螺釘較大或螺釘外形不利進入導軌槽時，將轉輪延時調長，反之螺釘較小時調短。


(3)導軌振動延時（VIBRATION）調整：
同樣，螺釘較大或外形不利進入導軌槽時，將振動延時調長，反之，螺釘較小時調短。

In order to check screw more easier,you need to pay attention to the following four-point

1. The turn table and the rail must be a central line, and the guide slot must suppress the screw cap.
2. Suggested that keep the elect ric screw driver revolving to take the bolt, like this will more labor-saving.
3. Every two months, moving parts should be added the appropriate lubricants, in order to maintain the normal operation.
4. When troubles appeared, such as screw struck, abnormal alarm, un-pleasant smell emanated, you should stop using and turn off the power immediately. Check the problems and adjust it. If you are unable to resolve the fault, please contact the dealer.

爲了使取螺釘更輕鬆，還需注意以下四點：


1. 轉盤必須與導軌對中，并且壓板必須將螺釘帽壓住；
2. 建議使電批旋轉着取螺釘，這樣將會更省力。
3. 運動部件每隔兩個月應適當加注潤滑油，以使運轉正常。
4. 當出現卡螺絲、報警器異常報警、產生難聞的氣味等異常情況時，應立即停止使用，關掉電源，檢查調整。如遇自己不能解決的故障，請聯系經銷商維修。



Circuit diagram of the signal lines

Signal line
信号线

接线方法如右图



附图：转盘和上板相对应规格型号

The appended drawings:

Wheel and upper corresponding specifocations

型号 model	螺丝 screw	转盘 turn table	导轨 rail	上板 upper plate
转盘式精密 螺丝供给机 Automatic screw feeder for robot	M1.0	M1.0	1.1	M1.0~M1.4
	M1.2	M1.2	1.3	
	M1.4	M1.4	1.5	
	M1.6	M1.6	1.7	M1.6~M2.0
	M1.8	M1.8	1.9	
	M2.0	M2.0	2.1	
	M2.3	M2.3	2.4	M2.5~M4.0
	M2.5	M2.5	2.7	
	M2.6	M2.6	2.8	
	M2.7	M2.7	2.9	
	M3.0	M3.0	3.2	
	M3.5	M3.5	3.7	
	M4.0	M4.0	4.2	

螺丝机的保养

序号	保养部位或组件	保养内容
1	导轨	1.每隔15日用酒精清洗(擦拭)导轨内侧面 2.建议每隔两个月对导轨用退磁器进行退磁
2	对射传感器	建议每隔半月对料满停机传感器用酒精擦拭清晰
3	齿轮传动副	对齿轮传动副应每隔三个月加注润滑油
4	传动杆滑动副	对传动杆滑动部位应每个三个月加注润滑油
5	直振	每隔半年对直线输送器的所有螺钉检查有无松动并紧固

The electric control part is composed of digital tubeco unters and circuit board, circuit board setting method is as follows: press the function key (the SET key), and keep 3 seconds, digital tube digital flicker, into the normal work mode setting interface, Press "▲" can switch cycle different patterns.

nn-10: suitable for M0.7 ~ M1.0 screw.

nn-12: suitable for M1.1 ~ M1.2 screw.

nn-14: suitable for M1.3 ~ M1.4 screw.

nn-17: suitable for M1.5 ~ M1.7 screw.

nn-20: suitable for M1.8 ~ M2.0 screw.

nn-26: suitable for M2.1 ~ M2.6 screw.

nn-30: suitable for M2.7 ~ M3.0 screw.

nn-40: suitable for M3.1 ~ M4.0 screw.

nn-50: suitable for M4.1 ~ M5.0 screw.

Press "SET" key again and return to work. At this point, the machine in accordance with the way of binding parameters in advance.

advanced work mode setting

1. Press "▼" key for 3 seconds, walk into the feeding speed regulation (1-30), the panel shows the numerical "A-***", press "▼" at this time, "▲" button can adjust the value.

2. Press "SET" key again, enter "vibration motor delay stop time" Settings. (0.0-6.0 S shown as "b-00-60"), press "▼" and "▲" key to adjust the time numerical size, every 0.5 seconds to jump for the unit, continue to hold down the "▼" and "▲" key can quickly adjust the value.

3. Press "SET" key again, enter "time delay stop feeding motor" Settings, (0.0-8.0 S shown as "C-00-80"), press "▼" and "▲" adjust numerical jump in every 0.5 seconds, continue to hold down the "▼" and "▲" key can quickly adjust the value.

4. Press the "SET" button, enter the working mode choice. Panel displays "-*d", according to "▲" button can switch different patterns.

d-0: said mode 0 (not counting mode)

d-1: choose model 1 (counting mode)

5. Press "SET" key again and return to the work mode.

电控部分由数码管计数器及电路板组成, 电路板设定方法如下: 按下功能设置键 (SET键), 并保持3秒, 数码管数字闪烁, 进入普通工作模式设定界面, 按 "▲" 键可以循环不同模式。

nn-10: 适用于M0.7~M1.0的螺丝。

nn-12: 适用于M1.1~M1.2的螺丝。

nn-14: 适用于M1.3~M1.4的螺丝。

nn-17: 适用于M1.5~M1.7的螺丝。

nn-20: 适用于M1.8~M2.0的螺丝。

nn-26: 适用于M2.1~M2.6的螺丝。

nn-30: 适用于M2.7~M3.0的螺丝。

nn-40: 适用于M3.1~M4.0的螺丝。

nn-50: 适用于M4.1~M5.0的螺丝。

再次按下 "SET" 键, 返回工作模式。这时, 机器依照预先绑定参数的方式工作。

高级工作模式设置

1. 按下 "▼" 键3秒, 进入送料速度调节 (1-30), 面板显示数值 "A-***", 此时按 "▼"、

"▲" 键可以调整该数值。

2. 再次按下 "SET" 键, 进入 "振动电机延时停止时间" 设置。(0.0-6.0S 显示为 "b-00-60")。

按 "▼"、"▲" 键调整该时间数值大小, 以每0.5秒为单位跳变, 持续按住 "▼"、"▲" 键可以快速调整数值。


3. 再次按下 "SET" 键, 进入 "延时停止上料电机时间" 设置。(0.0-8.0S 显示为 "C-00-80"), 按 "▼"、"▲" 键调整数值以每0.5秒为单位跳变, 持续按住 "▼"、"▲" 键可以快速调整数值。

4. 按下 "SET" 键, 进入工作模式选择。面板显示 "d-***", 按 "▲" 键可以切换不同模式。


d-0: 表示选择模式0 (不计数模式)


d-1: 表示选择模式1 (计数模式)

5. 再次按下 "SET" 键, 返回工作模式。






传动装置






直振组件





外观图



编号	中文名称	英文名称	数量
1	前面罩	Front cover	1
2	后面罩	Rear cover	1
3	电源开关	Power switch	1
4	右面罩	Right cover	1
5	左面罩	Left cover	1
6	盖板	Cover board	1
7	压板	Press plate	1
8	压板支架	Clamp holder	1
9	直振组件	Feeder	1
10	压板锁片	Pressing plate locking plate	1
11	传动组件	Transfer group	1
12	导轨组件	Screw rail	1
13	橡胶脚垫	Rubber foot	4
14	上板	Upper plate	1
15	转盘	Turntable	1
16	传感器支架	Sensor holder	1
17	等高柱	High column	4
18	大框架	Big frame	1
19	锁片	Locking plate	1
20	光电传感器支架	Photoelectric sensor holder	1
21	光电传感器	Photoelectric sensor	1
22	定位齿轮轴	Position gear shaft	1
23	滑动轴套	Sliding tube	2
24	滑动轴套	Sliding tube	1
25	转轮定位盘	Wheel positioning plate	1
26	大齿轮	Big gear wheel	1
27	大齿轮轴	The big gear shaft	1
28	滑动轴承	Sliding bearing	2
29	步进电机	Stepping motor	1
30	齿轮	Gear	1

部件名称表

编号	中文名称	英文名称	数量
31	步进电机支架	Stepper motor holder	1
32	保护板	Protective plate	1
33	对射传感器	Antithetic sensor	1
34	导轨左固定块	Guide left fixed block	1
35	导轨右固定块	Guide right fixed block	1
36	左导轨	Left screw rail	1
37	右导轨	Right screw rail	1
38	左导轨V型斗	Left rail V-funnel	1
39	右导轨V型斗	Right rail V-funnel	1
40	调整片1.2mm	Tabs 1.2mm	5
41	调整片0.2mm	Tabs0.2mm	5
42	导轨安装座垫片	Guide rail mount gasket	1
43	导轨安装座	Screw rail frame	1
44	弹簧片	Spring leaf	2
45	直振上板	Bottom connentor of feeder	1
46	振动电机支架	Vibration motor holder	1
47	偏心轮	Eccentric wheel	1
48	导向块	Guide block	1
49	直振下板	Upper connentor of feeder	1
50	振动电机	Vibration montor	1
51	料仓	Container	1
52	减速电机	Gear motor	1
53	减速电机支架	Motor holder	1
54	凸轮	Cam	1
55	传动轴支架	Axis holder	1
56	传动轴尼龙套	Nylon tube	1
57	小齿轮	Little gear	1
58	扇形齿	Sector gear	1
59	扇形齿衬套	Sector gear tube	1
60	上推杆支架尼龙套	Upper nylon tube	1

部件名称表

编号	中文名称	英文名称	数量
61	推杆支架	Brush lifter holder	1
62	压簧	Pressure spring	1
63	推杆	Brush lifter	1
64	下推杆支架尼龙套	Bottom nylon tube	1
65	推杆轴承套	Brush lifter tube	1
66	推杆轴承	The push rod bearing	1
67	毛刷支架	Brush holder	1
68	毛刷	Brush lifter	1
69	毛刷锁片	Brush connecting piece	1
70	毛刷摆动架	Brush oscillating rod	1
71	小齿轮	Little Gear	1
72	平垫	Washer	1
73	前板尼龙套	Nylon tube	1
74	右板	Right board	1
75	底板	Bottom board	1
76	电路板	Circuit board	1
77	电路板支架	Circuit board holder	1
78	塔簧	Tower spring	2
79	下挡料板	Screw block plate	1
80	上挡料板	Screw block plate	1
81	扇形齿安装卡簧	Circlip	1
82	前板	Front board	1
83	左板	Left board	1
84	中板	Middle board	1
85	中板轴承	Medium plate bearing	4
86	齿圈	Cera wheel	1
87	DC插座	DC socket	1
88	DC支架	DC socket	1